


DryerJack[®]

Roof Material Cut Template



Online Install Tips:

DryerJack.com/Install477



Installation Instructions Also on Reverse Side

DryerJack[®]

Model 477 Installation Instructions

Professional Installation is Recommended

1. **Determine location for roof vent installation.**
2. **Using this template, drill a pilot hole on the "X" to mark the center of hole location for ductwork.**
3. **Trace around the perimeter of template.**
4. **Cut away roof covering along the traced line.**
5. **From pilot hole mark, cut 4-1/4" circular hole into roof deck for ductwork.**
6. **If installing the RoofNeck™ collar, begin at Step 3 in those instructions and complete.**
7. **Apply roofing sealant along the underside of the flange.**
8. **Slide flange underneath the shingles.**
9. **Using the predrilled holes, secure to roof deck with corrosion resistant nails or screws.**
10. **Apply roofing sealant to underside of shingles and lay over flange.**
11. **Apply roofing sealant around base of the hood and exposed fasteners.**

Pilot Hole Template on Reverse Side